

TECHNICAL BULLETIN

June 25, 2020
ISSUE: 062520



Issues Associated with Improper Foot Pedal Installation for the PWT 3i


Summary:

If the touchless-dispense foot pedal is not installed properly, the touchpad on the PWT 3i unit may become non-responsive.

This bulletin details the root cause of the issue, how to troubleshoot if it occurs, and how to ensure proper installation to prevent it from happening.

THE ISSUE:

If this wire is pulled with too much force, the female ribbon connector will pull off the board. This may inadvertently occur when fishing the harness for the pedal and is therefore highly recommended to check all wire connections after installing the pedal



TROUBLESHOOTING:

If this occurs, you will notice a loss of total or partial function of the touchpad and/or foot pedal. Water will not dispense.


To resolve: Unplug your unit. Remove the front panel and correct the wire orientation according to the PWT 3i foot pedal installation guide.

PREVENTION:



Step 1:
Unplug unit from power and remove side panels.

Step 2:
Remove top front panels and gently remove ribbon wire.



Step 3:
Follow 3i foot pedal installation guide to install foot pedal and wire harness.

For additional tips or assistance, contact
Pure Water Technology technical support directly:
(855) 534-8332

